

Premier 4: Bearing for the Rollers

Rubber Roll Flange Bearing Oil-lite Bushing (PRB 048)

Top bearing support for the top front and back rollers (PRB 048) 4 required.

Bottom bearing support for the bottom front and back rollers. (PRB 048) 4 required.